

SNAP SAMPLER BOTTLE PREPARATION


40 ML VOA

TRIM SNAP CAPS


Version 11-07



(A)



(B)




(C)

- A) Snap Sampler VOA, removed from Snap Sampler.
- B) **[UNPRESERVED]** Carefully trim Snap Caps as flush as possible. **To trim first Snap Cap, hold ends with finger and thumb while clipping--making sure not to dislodge seal. Carefully screw on first septa cap--making sure not to dislodge seal; trim second Snap Cap; screw on second septa cap, then re-tighten both septa caps to secure.**
- C) Prepared, unpreserved bottle.
- D) **[PRESERVED]** After securing one end of the Snap VOA as described above, trim the second Snap Cap; add preservative to the cavity in the Snap Cap.
- E) **[PRESERVED]** Pierce the Snap Cap membrane with the pointed end of the Driver Tool to allow preservative to mix with the sample; top off preservative to form a meniscus, then secure the second septa cap.
- F) Prepared, preserved bottle.


ADD PRESERVATIVE (AS REQUIRED)



(D)



(E)



(F)


SNAP SAMPLER BOTTLE PREPARATION

125 ML POLY

(FOR ANALYTES WHERE AIR EXPOSURE AFTER COLLECTION IS NOT A CONCERN,
OTHERWISE FOLLOW PREPARATION PROCEDURE FOR 40 ML VOA ON REVERSE)

TRIM/REMOVE SNAP CAPS

Version 11-07



- A) Remove Snap POLY Bottle from Snap Sampler.
- B) **Trim one Snap Cap** (see step "B" on reverse); **secure septa cap lightly** (you will remove it in step "E" below).
- C) **Invert bottle and remove second Snap Cap by hooking the internal Spring over the lip of the bottle.**
- D) **Lift spring and release into the bottle using lip of septa cap; secure cap.**
- E) **Re-invert the bottle; remove septa cap; remove the Snap Cap and spring.**
- F) **Add preservative (if required), secure septa cap.**
- G) **Prepared bottle**

REMOVE SPRING

